


15. ASSEMBLY DRAWING



16. SPARE PARTS LIST

Pos. No.	Description	Qty.	Item No.
01	Nut M12	6	704063
02	Stud M12x25	6	708883
03	Bearing bracket	1	590750
04	Lock ring	1	701112
05	Shaft	1	590770
06	Lock ring	1	701125
07	Drain plug 3/8" BSP	1	2037505
08	Oil sealing ring	1	701292
09	Ball bearing 6010-2RS1	1	703381
10	Nipple 3/8"x40	1	710938
11	End plug 3/8" RG	1	190530
12	O-ring	1	710945
13	Nylon bushing	1	590760
14	Rear plate for rotor housing	1	190531
15	Allen screw M5x30	4	710940
16	Rotor	1	190532
17	Rotor housing	1	190533
18	Locating pin \varnothing 4x18	1	706284
19	Impeller	1	590730
20	Key 5x5x20	1	700012
21	Impeller nut M18x1.5	1	710943
22	Wear ring	1	590720
23	Stud M16x40 A4	8	710935
24	Nut M16 A4	8	704037
25	Filling plug 3/4"	1	706970
26	Stud M16x40 A4	8	710935
27	Nut M16 A4	8	704037
28	Gasket for inspection cover	1	190528
29	Inspection cover	1	190529
30	Nyloc nut M12	2	703232
31	Stud M12x25 A4	2	708883
32	Drain bolt 3/4"	1	190527
33	Ball bearing 5205	1	710937
34	Shaft seal	1	710936
36	O-ring for rotor housing	1	710946
37	Lock washer M18	1	710944
38	Pump casing	1	590710
39	Shaft end	1	590780
40	Allen screw M10x170 A4	1	710947
41	Key 7x8x50	1	706834
42	Key 7x8x40	1	700021